



Perimeter Wall Mount Glass Whiteboard Installation Instructions

Markerboard Installation Instructions

Z - Clips

Included: Z-clips (2), screws (4 or 6), zinc anchors (4 or 6), and template.

Not Included: Screwdriver, level, drill, and pencil.



1. Using tape, place template on desired location of wall.
 2. Adjust position of template using a level.
 3. Use a pencil to trace the rectangle cut-outs onto the wall. Once traced, the template can be removed from the wall.
 4. Line each z-clip up to the bottom line of the rectangle so that the side of the z-clip with holes is pressed against the wall and the lip of the z-clip is facing up.
 5. Zinc anchors (included) need to be inserted in the wall if there is not a stud in the location of the screw. After a zinc anchor has been secured, a screw can then be inserted through the z-clip and directly into the zinc anchor. If the screw is being inserted into a stud then no other hardware is required. If there is concrete or brick behind the wall then a masonry bit and concrete anchors will need to be used (not included).*Space the screws out evenly among the z-clips.
 6. Finally, place the markerboard against the wall and set the markerboard into place so that the z-clips attached to the markerboard fall into the z-clips attached to the wall.
-