



Clamp Privacy Screen (Above Desk Top, Side-to-Side) Installation Instructions

Step 1 – Put screen in clamps and secure with bolt. Note: longer bolt is used with 3/8" + screens and shorter bolt is used on 1/4" thick screens. MAKE SURE SCREEN IS SITTING ON LEDGE (see below) to get proper tension.

Step 2 – Remove double stick tape release paper (if desired). Place screen into position on top – the front clamp wraps around worksurface and the rear clamp sits on top of worksurface. Use wood screws (not shown) to secure front bracket to underside of top.

